


TOP VIEW



FRONT VIEW

NOTES:

- 1) PIPING SHOWN IN DASHED LINES - SUPPLIED BY CUSTOMER
- 2) ALLOW 1 FOOT ABOVE TANKS FOR LOADING
- 3) FLOW METER REQUIRES (15) PIPE DIAMETER LENGTHS BEFORE METER & (10) AFTER FOR PROPER OPERATION
- 4) FLOW METER SHOULD BE MOUNTED HORIZONTALLY

SHIPPING Wt.	.
OPERATING Wt.	.

BY:	No.	REVISION	DATE	CKD
.	0	PRELIMINARY	10/26/2010	.
.	1	.	.	.
.
.

Water King
WATER CONDITIONING

953302-11
MF-FG-300S-3 TWIN ALT.
GENERAL ARRANGEMENT

SCALE @ 24"x36"	DRAWING NUMBER	SHEET
N.T.S.	MF-FG-300-3T	01 / 0 1
www.waterking.com		

102 Charbonnet Rd., Duson, Louisiana, U.S.A. 70529

Telephone: (337) 988-2360 * Fax: (337) 981-7922